



WALLFLEX MAINTENANCE TIPS

Initial Care:

1. Allow adhesive about 48 hours to dry.
2. Clean surface with good quality neutral cleaner (Armstrong ONCE 'N DONE).

Ongoing Care:

1. Clean surface with good quality neutral cleaner (Armstrong ONCE 'N DONE).

Routine Maintenance:

Spray and wipe Wallflex with diluted neutral cleaner (Armstrong Once N'Done) and a clean cloth. Frequency and type of function depends on traffic flow, environmental conditions, access and customer requirements. Frequency may need to be adjusted depending on the prior conditions, especially if a light colour has been chosen.

Stain Removal:

Treatment should be carried out when stains are fresh. Use a white or red hand pad in combination with a neutral cleaner. After stains have been removed wipe with clean water.

General Hints:

1. **Surface can be cleaned using damp cloth containing Armstrong ONCE 'N DONE.**
2. **DO NOT USE** benzine, toluol, acetone, trichloroethene, thinner, oilwax or strong scouring powders as these will damage the wall material.
3. Spot cleaning / spot scrubbing should be used when necessary.

For further Armstrong information:

Freecall 1800 632 624
www.armstrong-aust.com.au