



Dimensions in millimetres and are nominal

Product Attributes

Armstrong flooring accessories are manufactured under strict quality control from a blend of quality raw materials and are designed to colour co-ordinate with Armstrong resilient flooring ranges and current interior design trends.

Armstrong Stair Nosing Insert

Flexible insert for fitting to aluminium or brass stair nosing to give a slip retardant finish.

Stair Nosing Insert *

- Hi-Vis yellow for increased visibility and safety
- Slip retardant

Available in

- 50mm x 26m coils
- 26mm x 26m coils

Custom colours are available on request in Standard Formulation only, *Stair Nosing Insert is stocked in Hi-Vis yellow as well as standard Black & Flint only, other standard colours are available, contact your Armstrong Representative or Customer Service for further information.

Specification

Where noted in the specification and/or schedule of finishes install Armstrong Stair Nosing Insert, colour as specified.

Install Armstrong Stair Nosing Insert (50mm or 26mm) to proprietary metal trim, such as aluminium or brass stair nosing or similar as supplied by others (install to manufacturers recommendations).

Armstrong flooring accessories should be fixed using **Armstrong SC-100** solvent based contact adhesive or construction adhesive (follow manufacturers directions).

Installation

Substrate

Installation of Armstrong flooring accessories must conform to AS 1884-1985. Special attention should be paid to AS1884-1985 section 2.1.1.3 Surface.

Stair Nosing Insert



Fitting

All material should be checked in good natural light for obvious defects prior to fitting; if material has defects immediately contact your supplier.

Install Armstrong Stair Nosing Insert (50mm or 26mm) to proprietary metal trim, such as aluminium or brass stair nosing or similar as supplied by others (install to manufacturer's recommendations).

Armstrong SC-100 Solvent Based Contact Adhesive

1. Ensure backing of Stair Nosing Insert is clean and free of dust.
2. Brush or roll (medium nap roller) Armstrong SC-100 Contact Adhesive on to the Stair Nosing Insert backing (ensuring full coverage).
3. Ensure substrate is clean and free from dust.
4. Using the chalk line as a guide, brush or roll (medium nap roller) Armstrong SC-100 Contact Adhesive on to the substrate (ensuring full coverage).
5. Allow both surfaces to dry for 10-15 minutes until "touch dry".
6. Ensure the Stair Nosing Insert is positioned correctly and fits neatly to substrate.
7. Using the chalk line as a guide, bring the two components together and bond together by applying pressure with a hand roller over the entire area.

Caution should be taken with SC-100, as this adhesive is highly flammable.

Maintenance

Damp wiping with a neutral cleaner (Armstrong Once n Done) for general maintenance. Solvent-based waxes or ammonia-based cleaners should be avoided.