



**CROSS MATCH CHART
FOR
ARMSTRONG WORLD INDUSTRIES
AND
BRUCE FLOORING**

Floor Sku	Flooring Name	COLOR-FILL REPAIR KIT
L0000	Mahogany/Orient Silk	638
L0001	Hague Oak/Pickled Oak	668
L0002	Western Hemlock/Chestnut	621
L0003	Beech/Royal Beech	630
L0004	Cherry/Vienna Cherry	676
L0005	Teak/Komi Teak	693
L0006	Natural Oak	623
L0006	Natural oak	623
L0007	Golden Oak/Dynasty Oak	693
L0008	Honey Oak/Amber Oak	675
L0100	Pioneer Oak Gunstock	645
L0101	Colonial Oak Honey	630
L0102	Hickory	621
L0103	Walnut	637
L0104	Plymouth Oak Natural	675
L0105	Royal Teak	658
L0106	Provincial Oak Blond	673
L0107	Provincial Oak Amber	623
L0108	Java Teak	651
L0109	Apple	640
L0110	Coconut	637
L0111	Caribbean Cherry Natural	620
L0112	Caribbean Cherry Royale	638
L0113	Acacia Sonora	676
L0114	Acacia Pecos	620
L0115	Acacia Torres	621
L0116	Pecan Amber	620
L0117	Pecan Natural	647
L0118	Merbau Antique	651
L0119	Merbau Natural	652
L0200	Liberty Oak	676
L0201	Hampton Oak Natural	640
L6066	Puerto Gold	L/624/D621/G643
L6067	Basalt	698/G696
L6068	Sand	696/G610
L6069	Caribbean Sand	658/G610
L6070	Monzone/Garden Stone	675/G610
L6071	Silver Sage	661/G610
L6072	Tunis	L639/D676/G664
L6073	Black Pearl	667/G661
L6074	Balla	690/G610
L0202	Maple Select	627
L0203	Amber Oak	630
L0204	Merbau	652
L0205	Kamballa	669
L0206	Brazilian Cherry Select	638
L0207	Brazilian Cherry Natural	676
L0208	Antique Hickory	
L0209	Windsor Maple	639
L0210	Concord	676
L0211	Franklin Maple	638
L0212	Black Forest	662
L0213	Morado	650
L0214	Noguera Walnut	656
Park Avenue	Flooring Name	COLOR-FILL REPAIR KIT
L3016	Ironwood Natural	637
L3017	Ironwood Amber	646
L3018	Pradoo	652
L3019	Makore	676
L3020	Exotic Walnut	620

Not Exact Match, will make new color and update when available, usually about six weeks