

## MAINTENANCE RECOMMENDATIONS

### POST INSTALLATION:

1. For the first 24 hours after your new floor is installed protect all the seamed areas and don't walk on the seam sealer.
2. Keep the room at 20 C or greater for at least a 2 days after installation to allow the adhesives to setup properly.
3. Do not roll heavy objects directly on to a newly installed vinyl floor for at least 5 days. This can cause the vinyl and adhesive to become compressed, once the adhesive sets up any compressed marks will become permanent. Always lay plywood or underlayment to disperse the weight of a heavy objects being moved across your vinyl floor.
4. Allow 5 days before thoroughly washing your floor. This will give time for the adhesive to cure. Before placing chairs or furniture on your new vinyl floor check the condition of all casters or rollers before setting the mon your floor. Replace any worn casters or rollers.

### REGULAR MAINTENANCE:

1. Dust, sand and grit particles are the enemy. Sweep or vacuum frequently. Don't use a vacuum with a beater bar as it may scratch your floor. And don't use scrub brushes.
2. When sweeping or vacuuming does not remove the dirt, mop the floor with clean warm water. Rinse the floor thoroughly with fresh water..
3. If water alone does not clean the surface, use cleaning products.
4. For spots or spills, wipe them up immediately and use the same technique on the spot as you would for the whole floor.
5. If you floor becomes dull looking you may need to add the manufacturer's recommended floor polish to restore the original gloss level.
6. Never use abrasive cleaners, soaps, paste waxes, or solvents on your vinyl floor.
7. Place non-staining, walk-off mat sate very outside entry to your room.

#### Armstrong World Industries (India) Pvt. Ltd.

Boomerang, A-304, Chandivali Farm Road (near Chandivali Studio) Andheri (E), Mumbai - 400 072  
Tel: 022-3048 0800, Fax: 022-3046 0439 / 2491 3604 | e-mail : helpdeskindia@armstrong.com

#### Branches:

Ahmedabad	: +91-85111 46309	Bengaluru	: +91-80-2657 6367	Chandigarh	: +91-172-2633 680
Chennai	: +91-44-4217 5303	Gurgaon	: +91-93126 73142	Hyderabad	: +91-40-3200 9868
Pune	: +91-20-3250 2404	Kolkata	: +91-33-2401 4755	Lucknow	: +91-522-220 1143

#### Representatives:

Bhopal	: +91-93237 99834	Bhubaneswar	: +91-99039 20499	Cochin	: +91-99477 87111
Coimbatore	: +91-93677 81490	Dehradun	: +91-93169 19120	Goa	: +91-93255 02140
Guwahati	: +91-99030 81018	Indore	: +91-93237 99834	Jaipur	: +91-93525 69512
Jammu	: +91-93169 19120	Ludhiana	: +91-93169 19120	Nagpur	: +91-93237 99834
Nashik	: +91-93255 02140	Patna	: +91-93126 73148	Raipur	: +91-93255 02140
Ranchi	: +91-99039 20499	Surat	: +91-85111 46309	Trivandrum	: +91-99477 87111
Vizag	: +91-93938 96055				