

## **A. TOOLS AND MATERIALS**

- Armstrong Laminate Flooring
- Armstrong Two-in-One™ Advanced Hard-Surface Flooring Underlayment or Moisture Barrier Sheeting
- Armstrong Laminate Flooring Accessories
  - Glue S-1800
  - Tapping Block S-1814
  - Pull Bar S-1812
  - Spacers S-1813
- Armstrong Laminate Flooring Coordinated Transitions & Moulding Pieces
  - Quarter-Round Moulding
  - End Moulding
  - T-Moulding
  - Reducer Strip
  - Flush Stairnose
  - Baby Threshold
  - Over-the-Top Step Nose
  - Wall Base
- Carpenter's Square
- Tape Measure
- 2"(5.1 cm) Wide Polyethylene Tape
- Hammer
- Utility Knife
- Safety Glasses
- NIOSH-Designated Dust Mask
- Saw (see optional tools)
- 100% Silicone Caulk (for bathroom & high moisture installations)
- Bucket of Warm Water
- Clean Cotton Cloths
- Touch-Up Kit/Filler Kit
- Plastic Scraper for Glue Removal



## B. OPTIONAL TOOLS AND MATERIALS

- Router
- Armstrong Laminate Flooring Router Bit
  - 7mm and 8mm Laminate: S-1824
  - 11mm Laminate: S-1828
- Armstrong Laminate Flooring Splines
  - 7mm and 8mm Laminate: S-1825
  - 11mm Laminate: S-1829
- Drill
- Saws
  - Table Saw
  - Miter Saw
  - Circular Saw
  - Hand Saw
  - Jigsaw
- Dividers
- Chalk Line
- Cleaner such as Armstrong Laminate Floor Cleaner
- White Vinegar
- Clamping System
- Pocket Plane

### **▲ CAUTION** WOOD DUST

**Sawing, sanding or machining wood products can produce wood dust. Airborne wood dust can cause respiratory, eye and skin irritation. The International Agency for Research on Cancer (IARC) has classified wood dust as a nasal carcinogen in humans.**

**Always follow the manufacturer's recommended safety instructions and practices when using power tools.**

#### **Precautionary measures if power tools are used:**

The power tools must be equipped with a dust collector. If high dust levels are encountered, use the appropriate NIOSH-designated dust mask. Avoid dust contact with eyes and skin.

#### **First aid measures in case of irritation:**

Flush eyes and skin with water for at least 15 minutes. Seek medical attention if irritation persists.

*Questions about Armstrong Laminate Flooring should be directed to our Consumer Solution Center at 1 800 233 3823.*

