



Dimensions in millimeters and are nominal

Product Attributes

Armstrong flooring accessories are manufactured under strict quality control from a careful blend of top grade raw materials and are designed to colour co-ordinate with Armstrong resilient flooring ranges and current interior design trends.

Wall Capping

A finishing strip to cover the exposed edge of vinyl wall or coved floor sheet on vertical surfaces to provide a cost effective solution for the protection of exposed vinyl edges up to 2mm.

Armstrong Wall Capping

- 12 colour ways*
- Subdued matte hues for a subtle finish
- The industry standard

Available in Standard formulation only

- 15 metre coils

Custom colours are available on request in Standard Formulation only, *Wall Capping is stocked in Black only, other standard colours are available, contact your Armstrong Representative or Customer Service for further information.

Specification

Where noted in the specification and/or schedule of finishes install Armstrong Wall Capping (colour as specified).

Wall Capping shall be installed to exposed horizontal edge of coved floor and/or wall vinyl sheet, butt the rebate in the back of Wall Capping to the edge of the vinyl.

Armstrong flooring accessories should be fixed using **Armstrong AC-100** 2 Part acrylic contact system or **Armstrong SC-100** solvent contact adhesive.

Installation

Substrate

Armstrong flooring accessories are suitable for installation on most internal building materials (such as concrete, timber, hardboard and rendered surfaces).

Inspection of the substrate; it shall be the responsibility of the sub-contractor to thoroughly examine the walls and doors prior to the application of vinyl sheet & accessories.

Wall surfaces must be dry, clean, smooth, structurally sound and free from moisture, alkali, dust, dirt, wax, oils, grease, loose paint or plaster, or any other foreign matter.

Rectification to imperfections in the surface of the substrate shall be made good prior to fixing vinyl sheet & accessories.

Installation of Armstrong flooring accessories must conform to AS 1884-1985. Special attention should be paid to AS1884-1985 section 2.1.1.3 Surface

Set out

To achieve a straight/level finish of Wall Capping, ensure that the desired height is marked at all external and internal corners. Strike a chalk-line between each point to act as a guide.

Fitting

All material should be checked in good natural light for obvious defects prior to fitting; if material has defects immediately contact your supplier.

All fitting work should be carried out before applying adhesive.

Install Armstrong coved floor and/or wall vinyl sheet to specified height, ensuring that edge is straight and level.

Wall Capping shall be installed to exposed horizontal edge of coved floor and/or wall vinyl sheet, butt the rebate in the back of Wall Capping to the edge of the vinyl.

Tight external and internal corners may require a groove to be cut from the back of the capping to a depth of 1/4 of the material.

Option 1

Armstrong AC-100 is a complete 2-Part Acrylic Contact System that replaces the use of traditional solvent based contact adhesives

Acrylic Contact System consists of **AC-100 Part-A** (Pre Coat) & **AC-100 Part-B** (Substrate Coat).

For successful installation AC-100 Part-A (Pre Coat) must be used in conjunction with AC-100 Part-B (Substrate Coat).

1. Ensure backing of the Wall Capping is clean and free of dust.
2. Brush or roll (medium nap roller) AC-100 Part-A on to the Wall Capping backing (ensuring full coverage), allow to dry.
3. Ensure substrate is clean and free from dust.
4. Using chalk line as a guide, brush or roll (medium nap roller) AC-100 Part-B on to the substrate (ensuring full coverage).
5. Allow AC-100 Part B to tack up (approx 15-20 minutes)
6. Ensure the Wall Capping pre-coated with AC-100 Part-A is positioned correctly and fits neatly to substrate coated with AC-100 Part-B (Substrate coat).
7. Using the chalk line as a guide, bring the two components together, apply heat and roll with a steel hand roller.

Option 2

Armstrong SC-100 Solvent Based Contact Adhesive

1. Ensure backing of Wall Capping is clean and free of dust.
2. Brush or roll (medium nap roller) Armstrong SC-100 Contact Adhesive on to the Wall Capping backing (ensuring full coverage).
3. Ensure substrate is clean and free from dust.
4. Using the chalk line as a guide, brush or roll (medium nap roller) Armstrong SC-100 Contact Adhesive on to the substrate (ensuring full coverage).
5. Allow both surfaces to dry for 10-15 minutes until "touch dry".
6. Ensure the Wall Capping is positioned correctly and fits neatly to substrate.
7. Using the chalk line as a guide, bring the two components together and bond together by applying pressure with a hand roller over the entire area.

Caution should be taken with SC-100, as this adhesive is highly flammable.

Maintenance

Damp wiping with a neutral cleaner (Armstrong Once n Done) for general maintenance. A light application of liquid floor polish/finish (Armstrong Shine Keeper) can be used to maintain gloss level. Solvent-based waxes or ammonia-based cleaners should be avoided.